

Download File PDF Honeywell 6160 User Manual

#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa



My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler



so many fake sites. this is the first one which worked! Many thanks

Honeywell

6160PX
AlphaProx Keypad

User Guide

This document provides operating instructions for using a proximity tag (referred to as a prox tag) with your AlphaProx Keypad. Refer to your security system User Guide for all other security system functions and operating procedures.

Prox Feature

The 6160PX Keypads are compatible with Prox Tags that can be used to alternately Arm and Disarm the system. Presenting a prox tag is functionally equivalent to entering a 4-digit security code.

Arming or Disarming the System


To arm or disarm the system, present the prox tag at the location of the Proximity Label (red eye) on the front of the keypad. The system beeps to confirm that it has been armed or disarmed.

Arming if system is disarmed:

System arms in the AWAY mode.

Disarming if system is armed:

System disarms and, if an alarm occurred, alarm sounding is silenced.



In the Event of an Alarm

If the system is armed and an alarm occurs, present your prox tag to silence the alarm and disarm the system. Present the tag a second time to clear the alarm from memory.

If a fire or carbon monoxide (CO) alarm occurs, you can silence the alarm with the prox tag, but you must use your 4-digit security code to clear the alarm from memory.

Presenting the tag a second time following a fire or carbon monoxide alarm will rearm the burglary portion of the system.

[Download PDF version of :](#)
Honeywell 6160 User Manual