

#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa



My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler




so many fake sites. this is the first one which worked! Many thanks

IV Troubleshooting

1. Jam Display

1.1 Misfeed Display

- When a paper misfeed occurs, the misfeed message, misfeed location, and paper location are displayed on the Touch Panel of the copier.



Display	Misfeed Location	Misfeed processing location	Action
[11]	1st Drawer take-up, 2nd Image Transfer, Fusing	Right Door	⇄ 4-5
[12]	2nd Drawer take-up, Vertical Transport	2nd Drawer Right Door	⇄ 4-6
[13]	Misfeed Bypass take-up	Manual Bypass Slide Board	⇄ 4-6
[14]	LCT take-up, Vertical Transport	LCT Right Door	⇄ 4-8
[15]	Duplex Unit transport	Duplex Unit Right Door	⇄ 4-11
[16]	3rd Drawer take-up, Vertical Transport	Paper Feed Unit Right Door	⇄ 4-9
[17]	4th Drawer take-up, Vertical Transport	Paper Feed Unit Right Door	⇄ 4-10
[18]	Exit	Right Door	⇄ 4-12
[19]	Horizontal transport	Horizontal transport cover	⇄ FS-501
[20]	Finisher FS-601	Finisher Door	⇄ FS-601
[21]	Finisher FS-501	Finisher Door	⇄ FS-501
[110]	Document Feeder DF-601	Document Feeder Door	⇄ DF-601

1.1.1 Misfeed Display Resetting Procedure

- Open the corresponding door, clear the sheet of paper misfeed, and close the door.

[Download PDF version of :](#)
Manual Konica Minolta Bizhub C350 Printer