

#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa



My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler



so many fake sites. this is the first one which worked! Many thanks

## SECTION 2

### CONTROLS & INDICATORS

#### LCD Control Center

**Setting the Clock**  
Setting the clock is optional. When the clock is set, the time will appear on the LCD Control Center. NOTE: You must set the clock if you will be using the Auto On/Off Time programming feature.

- Press the MENU/ Button.
- The word "OFF" will appear at the top of the LCD Control Center to indicate that the clock is not set. The programming options will appear on the LCD Control Center with a small arrow pointing to SET CLOCK. H (Hour) will appear above the LEFT Button and M (Minute) will appear above the RIGHT Button. The H and M icons and LEFT and RIGHT Buttons will flash.



- Press or hold the LEFT Button under the flashing H until you have reached the appropriate hour. If the hour has passed 12, the indicator switches from AM to PM.
- Press or hold the RIGHT Button under the flashing M to set the minutes.
- When you have reached the correct time, press the menu Button six times to scroll through the remaining programming options and exit the programming mode.
- The correct time should now be displayed on the LCD Control Center.

**NOTE:** If power is interrupted to the Brewer follow the procedure above to reset the time as the clock will not be visible until the time is set. Brew size and brew temperature menu settings are remembered and restored automatically. All other settings will be restored automatically after clock is set.

**Programming On/Off Features**  
The Brewer provides three modes so that you can enjoy gourmet coffee, tea or hot cocoa on your own schedule. By programming your Brewer to turn on each morning, you will never have to wait for the Brewer to warm up. It will take the Brewer approximately 3 1/2 minutes to warm up from room temperature.

- Leave Brewer ON All the Time (recommended).**  
The Brewer can be left on all the time so that it is always ready to brew a fresh cup of gourmet coffee, tea or hot cocoa. To turn the Brewer off at any time, simply press and release the Power Switch. (Note: Although the clock remains on, if set, you can not brew a cup of coffee, tea or hot cocoa.) Press and release the Power Button again to restore power to the Brewer. You will have to wait for the water to heat up before the Brewer is ready to brew.

- Set the Brewer to Turn Off at a Specified Period of Time After the Last Brew.**
  - Press the MENU/ Button twice to program the AUTO OFF feature. The LCD Control Center will now display the programming options with a small arrow next to SET AUTO OFF.



- Press or hold the LEFT Button under the flashing H to advance 1 hour at a time, up to 9 hours.

[Download PDF version of :](#)  
**Manual Page Maker 70**