

# Download File PDF Siemens Gigaset AL145 Manual

#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa



My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler



so many fake sites. this is the first one which worked! Many thanks

**Gigaset AL140/AL145**

**Handset**

**Base station**

**Please note:**  
New messages in the call log appear in blue. Network modification pages are indicated by a flashing icon in the display.

**1** Charge status of the battery pack  
**2** Internal number of the handset  
**3** Display keys  
**4** Message key  
**5** Directory key  
**6** Control key  
**7** Talk key  
**8** End call and On/Off key  
**9** Ringer on/off (press and hold in life status)  
**10** Keypad lock on/off (press and hold)  
**11** Recall key  
- Center (flash)  
- Dialing pause (press and hold)  
**12** Microphone  
**13** Alarm clock key

**Base station**

Registration/page key (page 6)

**Display keys:**  
Pressing the keys launches whatever function that appears above them in the display.

Display key	Function when pressed
INT	Call all registered handsets.
MENU	Open main/submenu (see Menu tree, page 11).
←	Go back one menu level.
→	Scroll left/right or adjust volume with <b>OK</b> .
↔	Move cursor to left/right with <b>OK</b> at a time.
↵	Backspace deletes one character at a time.
OK	Confirm menu/function or save entry.

**Safety precautions**

- Read this user guide and the safety precautions carefully before use. Explain their contents and the potential hazards associated with using the telephone to your children.
- Only use the mains unit supplied.
- Only use the approved, rechargeable battery pack, reuse a conventional (non-rechargeable) battery pack as this could result in significant health risk and personal injury. Batteries should not be disposed of in general household waste. Observe the local waste disposal regulations, which you can find out about by contacting your local authority or the dealer you purchased the product from.
- The operation of medical appliances may be affected. Be aware of the technical specifications of your particular environment, e.g. doctor's surgery.
- Do not hold the ear of the handset to your ear when it is ringing. Otherwise you risk serious and permanent damage to your hearing, that could also result in unpleasant humming/voiced ringing noise.
- Do not install the phone in a bathroom or shower room. The handset and base station are not splashproof.
- Do not use your phone in environments with a potential explosion hazard, e.g. paint shops.

**Gigaset service contact numbers:**  
For general advice on our range of products and for repairs or guarantee/warranty claims call:  
Service Centre UK: 08453 6708 12 (local call charge)  
Please have your proof of purchase ready when calling.

[Download PDF version of :](#)  
**Siemens Gigaset AL145 Manual**