#Jenny

Finally I get this ebook, thanks for all these I can get now!

#Rio

Cool! I'am really happy

#Markus Jensen

I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu

wtf this great ebook for free?!

#Che Salsa

My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler

so many fake sites. this is the first one which worked! Many thanks



Rinnai

Tankless Water Heater Service Manual

This manual provides service information for the models below. This table cross references each model to the applicable page number for internal component replacement instructions.

MODELS	DIAGNOSTICS	WIRE DIAGRAM	GAS CONTROL	FAN	RECIRCULATION	WATER FLOW CONTROL	HEAT EXCHANGER
R(C)62e, R(C)52e	10	28	41	49	54	59	64
R75e, R(C)65e(PLUS)	12	29	43	50	56	60	65
R(C)53i(Plus), R(C)53(PLUS)	12	30	43	51	56	60	65
R(C)65e(ASME)	14	31	45	52	56	61	66
R(C)65i(ASME)	14	31	45	52	56	61	66
V53e, R63Le	16	32	41	49	56	60	66
R95LSi, RTSLSi-VA	18	33	43	51	56	63	70
R95LSe2, RTSLSe-VA	18	33	43	50	56	63	70
R94LSe-VA	18	33	43	50	56	63	72
R94LSi-VA	18	33	43	51	56	63	70
RTSLSe-VB	20	34	47	50	56	63	72
RTSLSi-VB	20	34	47	51	56	63	70
R94LSe-VB	20	34	47	50	56	63	72
R94LSi-VB	20	34	47	51	56	63	70
V53i	20	35	43	51	56	63	70
R95LSe(ASME)	22	36	45	52	56	67	66
R95LSi(ASME)	22	36	45	52	56	67	66
RC80HPe	24	37	47	53	56	68	65
RC80HPi	24	37	47	53	56	68	65
RC98HPe	26	38	48	53	56	68	66
RC98HPi	26	38	48	53	56	68	66

Key to Trade Names in this Manual:

R/C — Indicates both the residential and commercial versions. R/C42e indicates R42e and C-42e.

RC — Indicates condensing water heater models.

(PLUS) — Indicates that the Designer Plus models are included. RC98ePLUS includes RS75e, C95e, and RS9ePLUS. On the side of the water heater, the trade name includes a "D", as in RSSDe.

(ASME) — Indicates that the ASME models are included. R94LSe (ASME) includes the R94LSe and R94LSe-ASME.

-VA -VB — The trade names R75LSe, R75LSi, R94LSe, and R94LSi have been given to both the VA and VB series of water heaters. Pay close attention to the particular model number when referencing electrical diagnostics, wire diagrams, gas pressures, replacement instructions, and for parts. When there is a difference –VA or –VB will be specified.

Some of the trade names for models were changed to indicate that their cartons included isolation valves and a pressure relief valve. For service and repair purposes the table below shows the equivalent models.

Model with valves in carton	Equivalent Model
RV53e	V53e
RV53i	V53i
RL75e	RTSLSe-VB
RL75i	RTSLSi-VB
RL94e	R94LSe-VB
RL94i	R94LSi-VB
RC80e	RC80HPe
RC80i	RC80HPi
RC98e	RC98HPe
RC98i	RC98HPi

100000309-R Rev B

Download PDF version of :

Rinnai Tankless Water Heater Service Manual