

#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa



My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler



so many fake sites. this is the first one which worked! Many thanks

BRAKES

PARKING BRAKE DISC SERVICE

2. Once you have determined the correct amount of discs to use, install the assembly bolts through the sleeves, insert the nuts and the correct amount of shims, the inner brake pad, springs, and outer brake pad. Torque the assembly nuts to 25 ft. lbs. (24 Nm).

Parking Brake Caliper - Assembly Bolts:
25 ft. lbs. (24 Nm)

3. Ensure the parking brake assembly functions properly by actuating the lever before installation.

Caliper Installation

1. Install the parking brake assembly into place. Tighten the two mounting bolts in increments for proper installation.

18 ft. lbs. (24 Nm)

Parking Brake Caliper - Mounting Bolts:
18 ft. lbs. (24 Nm)

2. Torque the two mounting bolts to 18 ft. lbs. (24 Nm).

Parking Brake Caliper - Mounting Bolts:
18 ft. lbs. (24 Nm)

3. Install the cable, pin, and clip pins. Test the park brake for proper function.

Disc Inspection / Removal (4x4)

1. Remove the brake disc with a prywrench. If the thickness of the disc is less than specified, replace the disc assembly.

2. Remove the outer P/V cover, belt, drive clutch, driven clutch and inner P/V cover (see Chapter 6).

3. Using a 1/2" socket and ratchet, remove the brake disc retaining bolt and remove the disc from the transmission.

New Disc: 0.164" - 0.173" (4.17 - 4.38 mm)
Service Limit: 0.147" (3.56 mm)

Apply Loctite™ 262

Remove Bolt

4. Reverse this procedure to reinstall the brake disc. Torque the disc mounting bolt to 15-18 ft. lbs. (20-24 Nm).

Disc Inspection / Removal (8x6)

1. Measure the brake disc with a micrometer. If the thickness of the disc is less than specified, replace the rear propshaft assembly.

2. Follow the rear prop shaft removal procedure listed in Chapter 7 to remove the rear propshaft assembly.

New Disc: 0.164" - 0.173" (4.17 - 4.38 mm)
Disc Service Limit: 0.147" (3.56 mm)

Remove Bolts

3. Refer to Chapter 7 to reinstall the rear propshaft assembly.

9.17

[Download PDF version of :](#)
2010 Polaris Ranger Service Manual